

Nuclear Control Systems



Shrouded Probe

ANSI N13.1 Particulate Sampling Probe

The Shrouded Sampling Probe is an anisokinetic probe manufactured by Ultra NCS Lab Impex Systems under licence from Texas A & M University. The probe is designed for high efficiency extraction of aerosols from ventilation stacks, and for the nuclear industry is most commonly used in radioactive effluent sampling and measurement systems.

Features

- Meets requirements for ANSI N13.1-1999 and ISO 2889-2010
- Available for 25mm, 1.0" or 1.5" sample lines
- Improved transmission efficiency over a range of velocities
- Improved transmission efficiency over a range of flow angles
- Lower internal wall losses than Isokinetic sample probes
- Less sensitive to flow turbulence
- Use in fixed or variable sample flow systems

This probe design has several advantages over nonshrouded probes (such as the traditional isokinetic variety): lower internal wall losses, better off-angle performance, lower sensitivity to flow stream turbulence, and the ability to operate in either a fixed flow or variable flow rate mode.

Another significant benefit is that a single probe design may be used for a range of stack velocities and geometries, thereby allowing a single shrouded sampling probe design to be used for a variety of different stack applications (diameters and flow rates). Shrouded probes are typically less expensive than a custom sampling rake designed for a similar stack.

Optimal Efficiency

In a stack installation, the shrouded probe will be used with a transport system specifically designed to ensure that aerosol losses within the sample probe and transport lines are kept to a minimum. Typically a system will comprise a shrouded probe, an in-stack transport line, a mounting flange, and an external transport line that conveys the aerosol sample from the stack to the sampling or monitoring system.

Transport system design is an important step in optimising overall sampling efficiency, and Lab Impex Systems can assist clients in the design process by using software modelling to determine the transmission efficiency of aerosol through the transport system.







+32 (0)3 309 32 09



Nuclear Control Systems



Shrouded Probe Model



Probe depth into duct (e.g. 450mm)

Wall thickness of duct/stack (e.g. 5mm) Mating flanged stand-off - duct OD to top face of flange (e.g. 75mm)

Straight length of "tail", flange face to end of tube (Typical length 190mm)

Mounting flange

- DIN 2527 PN6 100mm flange welded to the probe.
- DIN 2527 PN6 100mm flange fitted with locking gland. (Adjustable probe length)
 BS4504 Table 6 Class 150lb 4" flange welded to the probe. (Specify bolt hole position**)
 BS4504 Table 6 Class 150lb 4" fitted with locking gland. (Adjustable probe length)
- 3 ANSI B16.5 Class 150lb 4" flange welded to the probe. 4
- Universal Mounting Flange for 25mm probe.
- Universal Mounting Flange for 1" probe.
- (Specify bolt hole position**)

Part Number example SP2000-1-450-5-75-190-2-C

- (Specify bolt hole position**)
- (Adjustable probe length)
- (Adjustable probe length)

Please note that the Universal Mounting flange option is not available for a 1 ½" probe.

Bolt Hole orientation

- On centreline *
- Straddle centreline**
- Not applicable

***Note – Optimum velocity is where the transmission ration = 1





Ultra Electronics

NUCLEAR CONTROL SYSTEMS Impex House

21 Harwell Road Poole, Dorset, BH17 0GE,

England Tel: +44 1202 684848

Fax: +44 1202 8683571

www.ultra-ncs.com

www.ultra-electronics.com

PEO B.V.

info@gotopeo.com

www.gotopeo.com

The Netherlands

Havenweg 16, 6603 AS Wijchen

+31 (0)24 648 86 88

Belgium

+32 (0)3 309 32 09

Watermolenstraat 2, B-2910 Essen

CoC 34107894 VAT NL807859151B01 IBAN NL29 RABO 0356 1960 46 **BIC RABONL2U**

